

DUCAR

Diagramme de pièces *Parts diagram*





Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

D4000i Moteur *Engine*

MTI
CANADA

D4000i





Spare parts for the D4000i gasoline engine			
NO.	Code	Description	Qty
1	91347	BOLT M8X30	6
2	93507	OIL SEAL	2
3	245604	DIPSTICK	1
4	240116	COVER ASSEMBLY, CRANKCASE	1
5	96041	PACKING,CASECOVER	1
6	240901	DOWEL PIN,CASECOVER	2
7	93010	BALL BEARING	2
8	240364	CRANKSHAFT ASSEMBLY	1
9	332003	CAMSHAFT ASSEMBLY	1
10	246103	LIFTER,VALVE	2
11	241901	ROD,PUSH	2
12	91329	BOLT M6X16	8
13	245106	SWITCH ASSEMBLY,OIL LEVEL	1
14	330202	CRANKCASE	1
15	94007	WASHER,DRAIN PLUG	2
16	91816	BOLT, DRAIN PLUG	2
17	97431	STARTING MOTOR ASSEMBLY	1
18	91331	BOLT M6X25	2
19	241507	ROD ASSEMBLY., CONNECTING	1
20	245503	PIN, PISTON	1
21	241211	PISTON	1
22	241301	CLIP, PISTON	2
23	241607	SCRAPER RING SET ,PISTON	1
24	241021	CYLINDER HEAD	1
25	96182	PACKING,INTAKE	1
26	91029	BOLT, STUD	2
27	96051	PACKING,CARBURETOR	1
28	96058	GASKET,CYLINDER HEAD	1
29	240905	PIN, DOWEL	2
30	91007	BOLT, STUD	2
31	96055	PACKING,EXHAUST	1
32	91342	BOLT M8X12	2
33	249919	CAP,CENTRIFUGAL COVER	1
34	350901	DOWEL PIN,CASECOVER	2
35	91359	BOLT M8X60	4
36	97109	SPARK PULG	1
37	241704	VALVE,IN	1
38	245904	VALVE EXHAUST	1
39	241806	RETURNER,INTAKE VALVE	1
40	246001	SPRING,VALVE	2
41	241801	SEAT, VALVE SPRING,IN	1
42	241802	SEAT, VALVE SPRING,EX	1
43	241804	ROTATOR	1
44	242202	PLATE,PUSH ROD GUIDE	1
45	91818	Adjuster Rocker Arm	2
46	242101	ARM, ROCKER	2
47	96200	PACKING,HEADCOVER	1
48	241115	COVER COMP,CYLINDER HEAD	1

49	241116	COVER COMP,CYLINDER HEAD	1
50	91325	BOLT M6X12	7
51	330501	RECOIL STARTER W/FAN HOUSING ASSY	1
52	91864	BOLT	1
53	334501	CUP, FLYWHEEL	1
54	90003	NUT M14	1
55	334601	FAN, FLYWHEEL	1
56	500191	ROTOR	1
57	91400	BOLT M6X60	4
58	500190	STATOR	1
59	337001	AIR FILTER ASSEMBLY	1
59,1	5697	Foam filter	1
60	95602	TUBE,BREATHER	1
61	90016	NUT M6	4
62	94229	Air filter gasket	1
63	332808	CARBURETOR ASSEMBLY	1
64	339905	STEPPER MOTOR BRACKET	1
65	92055	CROSSING SCREW M4X25	3
66	249949	STEPPER MOTOR	1
67	249916	SHIELDING	1
68	92056	CROSS SCREW M4X6	4
69	249915	STEP MOTOR SEAT	1
70	332301	INSULATOR,CARBURETOR	1
71	332901	AIR CLEANER ASSEMBLY	1
71,1	5691	ELEMENT,AIR CLEANER	1
72	95918	TUBE,FUEL TANK TO CARBON	1
73	91330	BOLT M6X20	12
74	249917	BRACKET, AIR CLEANER	1
75	240511	SHROUD,UPPER	1
76	339902	THE TRIGGER	1
77	330503	SHROUD,RIGHT	1
78	339903	LGNITION COIL SUPPORT PLATE	1
79	249946	IGNITION COIL	1
80	330502	SHROUD,ABOVE	1
81	91333	BOLT M6X30	2
82	244306	Centrifugal fan housing.	1
83	244304	CAP,CENTRIFUGAL COVER	2
84	91345	BOLT M8X20	4
85	244606	FAN	1
86	334302	ISOLATOR	1
87	243740	MUFFLER COMP ASSY	1
88	94216	FLAT WASHER	2
89	94206	SPRING WASHER	2
90	90011	NUT M8	2
91	500057	SHIELD, MUFFLER	1
92	249914	CLAMP, CABLE CLAMP	1
93	94407	FUEL PIPE CLAMP	1
94	92007	CROSS SCREW M4X8	4
95	91831	OIL DRAIN SCREW PIPE	1
96	94035	DRAIN BOLT GASKET	1