

DUCAR

Diagramme de pièces *Parts diagram*




Le modèle peut différer légèrement de la photo / *The model may differ slightly from the picture*

DG6500

Moteur *Engine*

MTI
CANADA

DG6500



Spare parts for the DG6500 gasoline engine			
NO.	Code	Description	Qty
1	260218	CRANKCASE	1
2	93002	BALL BEARING	2
3	93511	OIL SEAL	2
4	93514	SEAL,GOVERNOR ARM SHAFT	1
5	263901	SHAFT,GOVERNOR ARM	1
6	96806	WASHER,GOVERNOR ARM SHAFT	1
7	263902	PIN,LOCK	1
8	91817	BOLT, DRAIN PLUG	2
9	94004	WASHER,DRAIN PLUG	2
10	265102	SWITCH ASSEMBLY,OIL LEVEL	1
11	91329	BOLT M6X16	2
12	240901	DOWEL PIN,CASECOVER	2
13	261205	PISTON	1
14	261604	SCRAPER RING SET ,PISTON	1
15	261503	ROD ASSEMBLY., CONNECTING	1
16	265501	PIN, PISTON	1
17	261301	CLIP, PISTON	2
18	260111	COVER ASSEMBLY, CRANKCASE	1
19	93015	BALL BEARING	1
20	264301	GOVERNOR ASSEMBLY	1
21	261002	CYLINDER HEAD	1
22	261702	VALVE,IN	1
23	265903	VALVE EXHAUST	1
24	261807	RETURNER,INTAKE VALVE	1
25	93513	OIL SEAL,VALVE	1
26	266002	SPRING,VALVE	2
27	260802	LOCKINMG FLAPS	4
28	261805	SEAT, VALVE SPRING,EX	2
29	262201	PLATE,PUSH ROD GUIDE	1
30	262101	ROCKER ASSY	2
31	261806	ROTATOR	2
32	91016	BOLT, STUD	2
33	91007	BOLT, STUD	2
34	96083	PACKING,EXHAUST	1
35	95207	EXHAUST PIPE	1
36	94206	SPRING WASHER	2
37	90011	NUT M8	2
38	262814	CARBURETOR ASSEMBLY	1
39	95451	FUEL LINE $\Phi 4 \times \Phi 8 \times 200$ mm	1
40	94403	CLIP,FUEL LINE $\Phi 7.5$	1
41	94401	RUBBER ,FUEL	1
42	264001	GOVERNOR ARM	1
43	91822	BOLT,GOVERNOR ARM	1
44	90016	NUT M6	3
45	260316	CRANKSHAFT ASSEMBLY	1

NO.	Code	Description	Qty
46	266101	LIFTER,VALVE	2
47	96072	PACKING,CASECOVER	1
48	260301	BALANCING SHAFT	1
49	262012	CAMSHAFT ASSEMBLY	1
50	91348	BOLT M8X35	2
51	91349	BOLT M8X40	7
52	260901	PIN, DOWEL	2
53	96089	GASKET,CYLINDER HEAD	1
54	91321	BOLT M10X80	4
55	97108	SPARK PULG	1
56	261901	ROD,PUSH	2
57	260501	SHROUD	1
58	91325	BOLT M6X12	9
59	261101	COVER COMP,CYLINDER HEAD	1
60	96075	PACKING,HEADCOVER	1
61	91819	LOCK BOLT	1
62	264404	SHROUD ASSY,UPPER	1
63	260402	FLYWHEEL ASSEMBLY	1
64	264601	FAN,RECOIL STARTER	1
65	264501	PULLEY,STARTER	1
66	90004	NUT	1
67	269901	RUBBER, STARTER ASSY	1
68	97518	IGNITION COIL ASSY	1
69	91331	BOLT M6X25	2
70	96078	PACKING,INTAKE	1
71	262301	INSULATOR,CARBURETOR	1
72	96081	PACKING,CARBURETOR	1
73	94227	GASKET,AIR CLEANER	1
74	262701	ROD,GOVERNOR	1
75	264201	SPRING,THROTTL RETURN	1
76	264724-026	RECOIL STARTER ASSEMBLY	1
77	260801	CLIP	2
78	262908	AIR CLEANER ASSEMBLY	1
79	95606	TUBE,BREATHER	1
80	264101	SPRING,GOVERNOR	1
81	245104	AMPLIFIER	1
82	265604	DIPSTICK	1
83	97210	CHARGE COIL	1
84	91334	BOLT M6X30	2
85	249901	CLAMPER CORD A	1
86	269902	CLAMPER CORD B	1
87	91340	BOLT M6X8	1
88	97406	STARTING MOTOR ASSEMBLY	1
89	91818	ADJUSTER ROCKER ARM	2
90	DJ188F/18700-A	STARTING MOTOR SOLENOID	1